



Step - 1

Position two Deck Clamps onto rib and tighten wing bolts. (Ensure jaws are located firmly on underside of rib.)




Step - 2

Slide the Support Bar into both Deck Clamps and tighten wing bolts.




Step - 3

Slide Bottom post onto the support bar and tighten wing bolt.




Step - 4

Slide the 2D post into the Bottom Post and tighten wing bolt. Make sure "D's" are facing working area.



Step - 5

Slide the 3rd rail clamp on the Bottom Post and tighten the L bolt. (Note: min. and max. from roof surface)



Step - 6

Slide the rails into 2D post and 3rd rail clamp and Tighten the L bolts.

